

Saetec - divisione **Essedomus**

Robbiate (Lecco) ITALY

www.essedomus.it

info@essedomus.it

MOUNTING INSTRUCTIONS

LARGE RECESSED FRAME cod. EB F04

To be used for Entry Box **SPACE BACK** and **TOWER BACK** only

To be used for fixing the mailbox in a niche realized in a wall or in the fence.

1. Determine the desired application area on the wall or iron fence.
Realize a niche through this area of approximately 44 cm in width and 80 cm in height to fully insert the frame and fix the 4 side brackets which must be walled or welded to the structure of the surrounding railings. If the brackets are too long, cut it accordingly.
2. Once the niche is ready, fix the 4 brackets on the side to the frame through the 3 supplied screws M5 using, tighten with the supplied hex key.
3. Set the frame in the niche fixing the brackets walled or welded to the railings of the fence.
4. Remove the 4 screws from the ledge, insert the mailbox into the frame compartment leaning it on the ledge, open the rear door and fasten the mailbox inside with 4 M5 screws using the key supplied.
5. Close the rear door. Your mailbox is ready to use.



Brackets

Mailbox
leaning ledge

SET 16

ESSEDOMUS
MADE IN ITALY